



**International
Standard**

ISO 14404-1

**Calculation method of carbon
dioxide emission intensity from
iron and steel production —**

**Part 1:
Steel plant with blast furnace**

*Méthode de calcul de l'intensité de l'émission de dioxyde de
carbone de la production de la fonte et de l'acier —*

Partie 1: Usine sidérurgique avec haut fourneau

**Second edition
2024-09**



COPYRIGHT PROTECTED DOCUMENT

© ISO 2024

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland