
**Calculation method of carbon dioxide
emission intensity from iron and steel
production —**

**Part 3:
Steel plant with electric arc furnace
(EAF) and coal-based or gas-based
direct reduction iron (DRI) facility**

*Méthode de calcul de l'intensité de l'émission de dioxyde de carbone
de la production de la fonte et de l'acier —*

*Partie 3: Usine de fabrication d'acier dans des fours électriques à arc
(FÉA) et installations de production de minerais de fer préreduits
avec procédés au charbon ou au gaz*





COPYRIGHT PROTECTED DOCUMENT

© ISO 2017, Published in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Ch. de Blandonnet 8 • CP 401
CH-1214 Vernier, Geneva, Switzerland
Tel. +41 22 749 01 11
Fax +41 22 749 09 47
copyright@iso.org
www.iso.org